

NOTICE

DO NOT DISPOSE OF BLACK TONER BOTTLE WHEN EMPTY.

This copier uses the empty black toner bottle as it's WASTE TONER bottle. Here's how!

1. Remove empty Black toner bottle from its position in the copier, and insert a fresh bottle.
2. Take the FULL waste toner bottle out of its position.
3. Take the EMPTY black toner bottle, and rotate it 180 degrees, to where the end connector is now upside down.
4. Insert the EMPTY black toner bottle firmly into the waste toner position. It may take just a little effort, but you should feel it click in. If the bottle is NOT fully inserted, the machine will alert you.

NOTICE: WASTE TONER MUST BE CHANGED AT THE SAME TIME AS THE BLACK TONER!! Failure to do so can cause unnecessary downtime as well as damage to your machine.